

























































VALVULA ACIONAMIENTO MANUAL 90°	DE	MAV_3 LES NC	MAV_5 LES OO	MAV_3 LEB NC	MAV_5 LEB OO	MAV_6 LEO CC	MAV_6 LEO OC	MAV_6 LEO PC	MAV_6 LES CC	MAV_6 LES OC	MAV_6 LES PC	
												
		1/8	7010000100	7010000200	7010000300	7010000400	7010000500	7010000600	7010000700	7010000900	7010001100	7010001000
		1/4	7020000100	7020000200	7020000300	7020000400	7020000500	7020000600	7020000700	7020001000	7020000900	7020001100
1/2	7030000100	7030000200	7030000300	7030000400	7030000500	7030000600	7030000700	7030001000	7030000900	7030001100		

70 BARRA		
		
2	221000200	222000200
3	221000300	222000300
4	221000400	222000400
5	221000500	222000500
6	221000600	222000600
7	221000700	222000700
70 PIES		
		
CORTO	221000192	222000192
ESTANDAR	221000191	222000191
LARGO	221000190	222000190
70 BASE MULTIPLE		
		
2	223000201	224000201
3	223000301	224000301
4	223000401	224000401
5	223000501	224000501
6	223000601	224000601
7	223000701	224000701
8	223000801	224000801
9	223000901	224000901
10	223001001	224001001
ACC. ADAPTADOR OMEGA		
		
	226004600	226005600
PLACA DE CIERRE		
		
	226004500	226005500
70 KIT DE JUNTAS DE DESGASTE		
	1/8	7010090000
	1/4	7020090000
	1/2	7030090000

ELECTROVALVULA		SOV_3 SOS NC	SOV_3 SOS NO	SOV_5 SOS 00	SOV_5 SOB 00	SOV_6 SOS CC	SOV_6 SOS OC	SOV_6 SOS PC	SOV_3 SES NC	SOV_5 SES 00	SOV A5 SOS 00
											
SIN BOBINA	1/8	SOV 23 SOS NC	SOV 23 SOS NO	SOV 25 SOS 00	SOV 25 SOB 00	SOV 26 SOS CC	SOV 26 SOS OC	SOV 26 SOS PC	SOV 23 SES NC	SOV 25 SES 00	
	1/4	SOV 33 SOS NC	SOV 33 SOS NO	SOV 35 SOS 00	SOV 35 SOB 00	SOV 36 SOS CC	SOV 36 SOS OC	SOV 36 SOS PC	SOV 33 SES NC	SOV 35 SES 00	SOV A5 SOS 00
	1/2	SOV 43 SOS NC	SOV 43 SOS NO	SOV 45 SOS 00	SOV 45 SOB 00	SOV 46 SOS CC	SOV 46 SOS OC	SOV 46 SOS PC	SOV 43 SES NC	SOV 45 SES 00	
12 DC	1/8	SOV 23 SOS NC	SOV 23 SOS NO	SOV 25 SOS 00	SOV 25 SOB 00	SOV 26 SOS CC	SOV 26 SOS OC	SOV 26 SOS PC	SOV 23 SES NC	SOV 25 SES 00	
	1/4	SOV 33 SOS NC	SOV 33 SOS NO	SOV 35 SOS 00	SOV 35 SOB 00	SOV 36 SOS CC	SOV 36 SOS OC	SOV 36 SOS PC	SOV 33 SES NC	SOV 35 SES 00	SOV A5 SOS 00
	1/2	SOV 43 SOS NC	SOV 43 SOS NO	SOV 45 SOS 00	SOV 45 SOB 00	SOV 46 SOS CC	SOV 46 SOS OC	SOV 46 SOS PC	SOV 43 SES NC	SOV 45 SES 00	
24 DC	1/8	SOV 23 SOS NC	SOV 23 SOS NO	SOV 25 SOS 00	SOV 25 SOB 00	SOV 26 SOS CC	SOV 26 SOS OC	SOV 26 SOS PC	SOV 23 SES NC	SOV 25 SES 00	
	1/4	SOV 33 SOS NC	SOV 33 SOS NO	SOV 35 SOS 00	SOV 35 SOB 00	SOV 36 SOS CC	SOV 36 SOS OC	SOV 36 SOS PC	SOV 33 SES NC	SOV 35 SES 00	SOV A5 SOS 00
	1/2	SOV 43 SOS NC	SOV 43 SOS NO	SOV 45 SOS 00	SOV 45 SOB 00	SOV 46 SOS CC	SOV 46 SOS OC	SOV 46 SOS PC	SOV 43 SES NC	SOV 45 SES 00	
24 AC	1/8	SOV 23 SOS NC	SOV 23 SOS NO	SOV 25 SOS 00	SOV 25 SOB 00	SOV 26 SOS CC	SOV 26 SOS OC	SOV 26 SOS PC	SOV 23 SES NC	SOV 25 SES 00	
	1/4	SOV 33 SOS NC	SOV 33 SOS NO	SOV 35 SOS 00	SOV 35 SOB 00	SOV 36 SOS CC	SOV 36 SOS OC	SOV 36 SOS PC	SOV 33 SES NC	SOV 35 SES 00	SOV A5 SOS 00
	1/2	SOV 43 SOS NC	SOV 43 SOS NO	SOV 45 SOS 00	SOV 45 SOB 00	SOV 46 SOS CC	SOV 46 SOS OC	SOV 46 SOS PC	SOV 43 SES NC	SOV 45 SES 00	
110 AC	1/8	SOV 23 SOS NC	SOV 23 SOS NO	SOV 25 SOS 00	SOV 25 SOB 00	SOV 26 SOS CC	SOV 26 SOS OC	SOV 26 SOS PC	SOV 23 SES NC	SOV 25 SES 00	
	1/4	SOV 33 SOS NC	SOV 33 SOS NO	SOV 35 SOS 00	SOV 35 SOB 00	SOV 36 SOS CC	SOV 36 SOS OC	SOV 36 SOS PC	SOV 33 SES NC	SOV 35 SES 00	SOV A5 SOS 00
	1/2	SOV 43 SOS NC	SOV 43 SOS NO	SOV 45 SOS 00	SOV 45 SOB 00	SOV 46 SOS CC	SOV 46 SOS OC	SOV 46 SOS PC	SOV 43 SES NC	SOV 45 SES 00	
220 AC	1/8	SOV 23 SOS NC	SOV 23 SOS NO	SOV 25 SOS 00	SOV 25 SOB 00	SOV 26 SOS CC	SOV 26 SOS OC	SOV 26 SOS PC	SOV 23 SES NC	SOV 25 SES 00	
	1/4	SOV 33 SOS NC	SOV 33 SOS NO	SOV 35 SOS 00	SOV 35 SOB 00	SOV 36 SOS CC	SOV 36 SOS OC	SOV 36 SOS PC	SOV 33 SES NC	SOV 35 SES 00	SOV A5 SOS 00
	1/2	SOV 43 SOS NC	SOV 43 SOS NO	SOV 45 SOS 00	SOV 45 SOB 00	SOV 46 SOS CC	SOV 46 SOS OC	SOV 46 SOS PC	SOV 43 SES NC	SOV 45 SES 00	
VALVULA ACIONAMIENTO NEUMATICO	DE	PNV_3 SOS NC	PNV_3 SOS NO	PNV_3 SOS 00	PNV_3 SOB 00	PNV_6 SOS CC	PNV_6 SOS PC	PNV_6 SOS OC			
											
	1/8	PNV 23 PNS NC	PNV 23 PNS NO	PNV 25 PNS 00	PNV 25 PNB 00	PNV 26 PNS CC	PNV 26 PNS OC	PNV 33 PNM NC			
	1/4	PNV 33 PNS NC	PNV 33 PNS NO	PNV 35 PNS 00	PNV 35 PNB 00	PNV 36 PNS CC	PNV 36 PNS OC	PNV 36 PNS PC			
	1/2	PNV 43 PNS NC	PNV 43 PNS NO	PNV 45 PNS 00	PNV 45 PNB 00	PNV 46 PNS CC	PNV 46 PNS OC	PNV 46 PNS PC			
VALVULA ACIONAMIENTO MECANICO	DE	MEV 23 BRS NC	MEV 25 BRS OO	MEV 23 URS NC	MEV 25 URS OO	MEV 23 RSS NC	MEV 25 RSS NC	MEV 23 ASS NC	MEV 25 ASS OO	MEV 23 LLS NC	
											
	1/8	MEV 23 BRS NC	MEV 25 BRS OO	MEV 23 URS NC	MEV 25 URS OO	MEV 23 RSS NC	MEV 25 RSS OO	MEV 23 ASS NC	MEV 25 ASS OO	MEV 23 LLS NC	
VALVULA ACIONAMIENTO MANUAL FRONTAL	DE	MAV_3 VLB OO	MAV_5 VLB OO	MAV 25 PPS OO	MAV 25 PPB OO						
											
	1/8	MAV 23 VLB OO	MAV 25 VLB OO	MAV 25 PPS OO	MAV 25 PPB OO						
	1/4	MAV 33 VLB OO	MAV 35 VLB OO								

VALVULA ACIONAMIENTO MANUAL 90°	DE										
	1/8	MAV 23 LES NC	MAV 23 LEB OO	MAV 25 LES OO	MAV 25 LEB OO	MAV 26 LEO CC	MAV 26 LEO OC	MAV 26 LEO PC	MAV 26 LES OC	MAV 26 LES PC	MAV 26 LES CC
	1/4	MAV 33 LES NC	MAV 33 LEB OO	MAV 35 LES OO	MAV 35 LEB OO	MAV 36 LEO CC	MAV 36 LEO OC	MAV 36 LEO PC	MAV 36 LES CC	MAV 36 LES OC	MAV 36 LES PC
	1/2	MAV 43 LES NC	MAV 43 LEB OO	MAV 45 LES OO	MAV 45 LEB OO	MAV 46 LEO CC	MAV 46 LEO OC	MAV 46 LEO PC	MAV 46 LES CC	MAV 46 LES OC	MAV 46 LES PC

70 BARRA		
		
2	CSA 18-02	CSA 14-02
3	CSA 18-03	CSA 14-03
4	CSA 18-04	CSA 14-04
5	CSA 18-05	CSA 14-05
6	CSA 18-06	CSA 14-06
7	CSA 18-07	CSA 14-07
70 PIES		
		
CORTO	CSA 18-OE	CSA 14-OE
ESTANDAR	CSA 18-OC	CSA 14-OC
LARGO	CSA 18-OO	CSA 14-OO
70 BASE MULTIPLE		
		
2	CVM 18-02	CVM 14-02
3	CVM 18-03	CVM 14-03
4	CVM 18-04	CVM 14-04
5	CVM 18-05	CVM 14-05
6	CVM 18-06	CVM 14-06
7	CVM 18-07	CVM 14-07
8	CVM 18-08	CVM 14-08
9	CVM 18-09	CVM 14-09
10	CVM 18-10	CVM 14-10
ACC. ADAPTADOR OMEGA		
		
	OMEGA 1/8	OMEGA 1/4
PLACA DE CIERRE		
		
	CVM 18 PCS	CVM 14 PCS
70 KIT DE JUNTAS DE DESGASTE		
	1/8	KIT S70 1/8
	1/4	KIT S70 1/4
	1/2	KIT S70 1/2